


RYCO FILTERS



PLUG USAGE INSTRUCTIONS FOR RYCO OIL FILTER R2722P

**USE PLUGS TO PREVENT DUST, DIRT ETC ENTERING
INLET AND OUTLET HOUSING PORT
WHEN HOUSING CAP IS DISCONNECTED.**



Ryco Group Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

RYCO Group
A division of GUD NZ Holdings Ltd
626A Rosebank Road Avondale
Auckland, New Zealand