

ISUZU D-MAX (08/2020 ../ON), MAZDA BT50 (09/2020 ../ON)

FILTER IS LOCATED BEHIND GLOVEBOX



STEP 1

The cabin air filter housing is located behind the glove box. To gain access, the glovebox must be removed.



STEP 2

Release the glove box from its securing hinge. Apply pressure to the far upper corners towards the inside of the compartment as indicated in the pic and slowly drop the unit.



STEP 3

With the glove box removed the housing is located above the blower fan. Remove the housing lid and remove the dirty filter. Remove and clean any remaining debris in the housing.



STEP 4

Insert the new filter into the housing. Look for UP arrow mark on one of the sides of the filter to identify position direction. Refit all components in reverse order.